



HOPPER INSTRUCTIONS

4-8 years

Item # Item No: 9301
Item No: 9302
Item No: 9304


Parts Included:
1x Hopper, 1x Stopper

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.


CAUTION: Adult supervision required at all times.
Minimum weight 32lbs. (14kgs)
Maximum weight of Child Not to Exceed 64lbs. (29kgs)
Do Not Over Inflate.




ALWAYS KEEP BOTH HANDS ON THE HANDLE.



MOUNT HOPPER AS SHOWN



ENSURE YOU BOUNCE UP & DOWN




FOR SAFE PLAY:

- ADULTS:** Stand next to your child as they mount hopper with both feet flat on ground. Make sure child adjusts themselves until they are seated comfortably so they don't lose balance.
- Hold firmly with both hands and look forward.
- Gradually start out with small hopping forward movements to ensure balance and confidence.




IMPORTANT HOPPER SAFETY & SETUP INSTRUCTIONS:


THE MANUFACTURER AND ITS DISTRIBUTORS ASSUME NO LIABILITY OR RESPONSIBILITY FOR ACCIDENTS OR INJURY TO PERSONS OR PROPERTY THAT MIGHT RESULT IN CONNECTION WITH THE USE OF THIS TOY. PLEASE READ AND SAVE THESE INSTRUCTIONS BEFORE SETUP AND USE. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE. ADULT SETUP IS REQUIRED.



A



B



C

TO INFLATE (Pump not included):

- Insert pump nozzle into the hole on the ball. A adapter may be needed (Adapter not included) which comes with most air pumps.
- Pump until inflated to a maximum of 18" diameter.
- When fully inflated, remove the pump adapter and push the stopper into the hole quickly and firmly. The hopper is then ready to use.

TO DEFLATE: Remove the stopper from the hole. Press ball flat and fold for storage.

**Minimum Weight of Child 32lbs (14kgs)
Maximum Weight of Child 64lbs (29kgs)**

DURING USE:

- DO NOT LET ANYONE UNDER THE AGE OF 4 USE THIS PRODUCT.**
- Competent adult supervision is required at all times. Responsible adults should instruct children on proper use of this toy.
- Remove all hard or sharp objects such as toys, buckles, keys, jewelry watches, etc. from person and pockets.

CAUTION: DO NOT OVER INFLATE.

Before each use, check the area and clothing for sharp objects to prevent puncture. Always keep a distance of 10 ft. or more from others while playing. When playing with this product, stay away from stairs, pools and roadways. Adult supervision required when playing with this product. If using an electric pump, make sure water is not present.

USE AND CARE INSTRUCTIONS: IMPORTANT:

This hopper is manufactured to the highest standard. Every ball has been inflated and tested before packing. Keep away from sharp objects that could cause damage. Keep away from heated surfaces. Use on clean, smooth surface. Inflate ball at room temperature. To prevent premature material fatigue, refrain from exposing the product to sunlight unnecessarily. Over sun exposure may cause leakage. Wash with soft, damp cloth. Do not use soap or any cleaning chemicals.

WARNING!

To avoid the risk of serious injury or death:
• Adult supervision required.
• Adult assembly required.
• This product is intended to be used as a toy and not as a personal flotation device.
• Do not use a high-pressure pump to inflate.
• Do not over-inflate.
• Do not use electric air pump if water or moisture is present. This may result in electric shock.
• Read all instructions before using this product.
• Disregard of and not following the instructions from the manual and warnings could result in injury or death, especially for children.
• Use product only on a grassy, level surface, clear of any obstructions, hard objects of debris. Failure to do so may result in cuts, bruises, or other injuries.

Colors and decorations may vary.

ATTENTION: PLEASE DO NOT RETURN TO STORE.

CONTACT US DIRECTLY FOR A REPLACEMENT

For more information or questions, Please call customer service..... 1-888-752-Toyz (8699)

Send us an email at..... help@bettertoyz.com

Write to us at: 2015 BETTER SOURCING WORLDWIDE, LTD. 6067 HOLLYWOOD BLVD., SUITE #355, HOLLYWOOD, FL 33024

www.littletikes.com

© The Little Tikes Company, an MGA Entertainment company. LITTLE TIKES® is a trademark of Little Tikes in the U.S. and other countries. All logos, names, characters, likenesses, mages, slogans, and packaging appearance are the property of Little Tikes. Used under license by Better Sourcing Worldwide, LTD.

bettertoyz © 2015 Better Sourcing Worldwide, Ltd.

Made in China